

ACL CURTAIN™

user manual



©2015 ELATION PROFESSIONAL all rights reserved. Information, specifications, diagrams, images, and instructions herein are subject to change without notice. ELATION PROFESSIONAL logo and identifying product names and numbers herein are trademarks of ELATION PROFESSIONAL. Copyright protection claimed includes all forms and matters of copyrightable materials and information now allowed by statutory or judicial law or hereinafter granted. Product names used in this document may be trademarks or registered trademarks of their respective companies and are hereby acknowledged. All non-ELATION brands and product names are trademarks or registered trademarks of their respective companies.

ELATION PROFESSIONAL and all affiliated companies hereby disclaim any and all liabilities for property, equipment, building, and electrical damages, injuries to any persons, and direct or indirect economic loss associated with the use or reliance of any information contained within this document, and/or as a result of the improper, unsafe, insufficient and negligent assembly, installation, rigging, and operation of this product.

Elation Professional USA | 6122 S. Eastern Ave. | Los Angeles, CA. 90040 323-582-3322 | 323-832-9142 fax | www.elationlighting.com | info@elationlighting.com

Elation Professional B.V. | Junostraat 2 | 6468 EW Kerkrade, The Netherlands +31 45 546 85 66 | +31 45 546 85 96 fax | www.elationlighting.eu | info@elationlighting.eu

DOCUMENT VERSION



Please check www.elationlighting.com for the latest revision/update of this manual.

Date	Document Version	Software Version	DMX Channel Modes	Notes
9/30/15	1	≥1.12	1CH:04 / 2CH:04 / 6 1CH:08 / 2CH:08	Initial release.
			10 / 12 / 56 / 58 / 60 / 63	



CONTENTS

General Information	4
Warranty	6
Safety Instructions	7
General Guidelines	8
Fixture Overview	9
Fixture Installation	10
Fixture Menu	12
DMX Channel Functions And Values	15
Cleaning and Maintenance	21
Technical Specifications	22
Optional Accessories	25



GENERAL INFORMATION

INTRODUCTION

Congratulations, you have just purchased one of the most innovative and reliable lighting fixtures on the market today! The fixture has been designed to perform reliably for years when the guidelines in this booklet are followed. Please read and understand the instructions in this manual carefully and thoroughly before attempting to operate this unit. These instructions contain important information regarding safety during use and maintenance.

UNPACKING

Every fixture has been thoroughly tested and has been shipped in perfect operating condition. Carefully check the shipping carton for damage that may have occurred during shipping. If the carton appears to be damaged, carefully inspect your unit for damage and be sure all accessories necessary to operate the unit have arrived intact. In the event damage has been found or parts are missing, please contact our customer support team for further instructions. Please do not return this unit to your dealer without first contacting customer support at the number listed below. Please do not discard the shipping carton in the trash. Please recycle whenever possible.

BOX CONTENTS

- (1) powerCON Cable
- (1) Glare Shield
- (1) Frost Filter
- Manual & Warranty Card



CUSTOMER SUPPORT

Elation Professional® provides a customer support line, to provide set up help and to answer any question should you encounter problems during your set up or initial operation. You may also visit us on the web at www.elationlighting.com for any comments or suggestions. For service related issue please contact Elation Professional®.

ELATION SERVICE USA - Monday - Friday 8:00am to 5:00pm PST

Voice: 323-582-3322 Fax: 323-832-9142

E-mail: support@elationlighting.com

ELATION SERVICE EUROPE - Monday - Friday 08:30 to 17:00 CET

Voice: +31 45 546 85 30 Fax: +31 45 546 85 96

E-mail: support@elationlighting.eu

WARRANTY REGISTRATION

Please complete and mail in the enclosed warranty card or register online: http://www.elationlighting.com/Login.aspx All returned service items whether under warranty or not, must be freight pre-paid and accompany a return authorization (R.A.) number. The R.A. number must be clearly written on the outside of the return package. A brief description of the problem as well as the R.A. number must also be written down on a piece of paper and included in the shipping container. If the unit is under warranty, you must provide a copy of your proof of purchase invoice. Items returned without a R.A. number clearly marked on the outside of the package will be refused and returned at customer's expense. You may obtain a R.A. number by contacting customer support.

IMPORTANT NOTICE!

There are no user serviceable parts inside this unit. Do not attempt any repairs yourself; doing so will void your manufactures warranty. Damages resulting from modifications to this fixture and/or the disregard of safety and general user instructions found in this user manual void the manufactures warranty and are not subject to any warranty claims and/or repairs.



LIMITED WARRANTY

- A. Elation Professional® hereby warrants, to the original purchaser, Elation Professional® products to be free of manufacturing defects in material and workmanship for a period of two years (730 days), and Elation Professional® product rechargeable batteries to be free of manufacturing defects in material and workmanship for a period of six months (180 days), from the original date of purchase. This warranty excludes discharge lamps and all product accessories. This warranty shall be valid only if the product is purchased within the United States of America, including possessions and territories. It is the owner's responsibility to establish the date and place of purchase by acceptable evidence, at the time service is sought.
- B. For warranty service, send the product only to the Elation Professional® factory. All shipping charges must be pre-paid. If the requested repairs or service (including parts replacement) are within the terms of this warranty, Elation Professional® will pay return shipping charges only to a designated point within the United States. If any product is sent, it must be shipped in its original package and packaging material. No accessories should be shipped with the product. If any accessories are shipped with the product, Elation Professional® shall have no liability what so ever for loss and/or or damage to any such accessories, nor for the safe return thereof.
- C. This warranty is void if the product serial number and/or labels are altered or removed; if the product is modified in any manner which Elation Professional® concludes, after inspection, affects the reliability of the product; if the product has been repaired or serviced by anyone other than the Elation Professional® factory unless prior written authorization was issued to purchaser by Elation Professional®; if the product is damaged because not properly maintained as set forth in the product instructions, guidelines and/or user manual.
- D. This is not a service contract, and this warranty does not include any maintenance, cleaning or periodic check-up. During the periods as specified above, Elation Professional® will replace defective parts at its expense, and will absorb all expenses for warranty service and repair labor by reason of defects in material or workmanship. The sole responsibility of Elation Professional® under this warranty shall be limited to the repair of the product, or replacement thereof, including parts, at the sole discretion of Elation Professional®. All products covered by this warranty were manufactured after January 1, 1990, and bare identifying marks to that effect.
- E. Elation Professional® reserves the right to make changes in design and/or performance improvements upon its products without any obligation to include these changes in any products theretofore manufactured.
- F. No warranty, whether expressed or implied, is given or made with respect to any accessory supplied with the products described above. Except to the extent prohibited by applicable law, all implied warranties made by Elation Professional® in connection with this product, including warranties of merchantability or fitness, are limited in duration to the warranty periods set forth above. And no warranties, whether expressed or implied, including warranties of merchantability or fitness, shall apply to this product after said periods have expired. The consumer's and/or dealer's sole remedy shall be such repair or replacement as is expressly provided above; and under no circumstances shall Elation Professional® be liable for any loss and/or damage, direct and/or consequential, arising out of the use of, and/or the inability to use, this product.
- G. This warranty is the only written warranty applicable to Elation Professional® products and supersedes all prior warranties and written descriptions of warranty terms and conditions heretofore published.



SAFETY INSTRUCTIONS



This fixture is an extremely sophisticated piece of electronic equipment. To guarantee a smooth operation, it is important to follow the guidelines in this manual. The manufacturer of this device will not accept responsibility for damages resulting from the misuse of this fixture due to the disregard of the information printed in this manual.



This device falls under **PROTECTION CLASS 1**. It's essential this device be grounded properly. Only qualified personnel should perform all electrical connections.



INDOORS USE ONLY!
DONOT EXPOSE FIXTURE RAIN AND MOISTURE!



UNPLUG POWER BEFORE SERVICING FIXTURE!

DO NOT PLUG FIXTURE INTO A DIMMER PACK!

NEVER TOUCH FIXTURE DURING OPERATION, AS IT MAY BE HOT!



NEVER LOOK DIRECTLY INTO THE LIGHT SOURCE!
SENSITIVE PERSONS MAY SUFFER AN EPILEPTIC SHOCK!

- For proper operation, follow the **Installation** guidelines described in this manual. Only qualified
 and certified personnel should perform installation of this fixture and only the original rigging parts
 (brackets) included with this fixture should be used for installation. Any modifications will void the
 original manufactures warranty and increase the risk of damage and/or personal injury.
- Never look directly into the light source of this fixture to prevent risk of injury to your retina, which
 may induce blindness. Those suffering from EPILEPSY should avoid looking directly into the light
 source of this unit at all times.
- The fan and air inlets must remain clean and never blocked. Allow approx. 6" (15cm) between this fixture and other devices or a wall for proper cooling.
- Always disconnect from main power source before performing any type of service and/or cleaning procedure. Only handle the power cord by the plug end, never pull out the plug by tugging the wire portion of the cord.
- Do not operate this fixture if the power cord has become frayed, crimped and/or damaged. If the power cord is damaged, replace it immediately with a new one of similar power rating.




GENERAL GUIDELINES

NEVER OPEN THIS FIXTURE WHILE IN USE!

- During the initial operation of this fixture, a light smoke or smell may emit from the
 interior of the fixture. This is a normal process and is caused by excess paint in the
 interior of the casing burning off from the heat associated with the lamp and will
 decrease gradually over time.
- This fixture is a professional lighting effect designed for INDOOR / DRY LOCATIONS
 ONLY on stage, in nightclubs, theatres, etc.
- Please make sure there are NO FLAMMABLE MATERIALS close to the fixture while operating, to prevent any fire hazard.
- The fixture must be installed in a location with adequate ventilation, at least 1.5 feet (.5m) from adjacent surfaces. Be sure no air ventilation slots are blocked.
- DO NOT attempt installation and/or operation without knowledge how to do so.
- DO NOT permit operation by persons who are not qualified to operate this type
 of fixture. Most damages are the result of operations by nonprofessionals.
- Consistent operational breaks may ensure the fixture will function properly for many years to come.
- **DO NOT** shake fixture, avoid brute force when installing and/or operating fixture.
- Always install the fixture with an appropriate safety cable. When installing the
 fixture in a suspended environment, always use mounting hardware that is no less
 than M10 x 25 mm, also be sure the hardware is insert in the pre-arranged screw
 holes in the bracket of the fixture.
- Use the original packaging and materials to transport the fixture in for service.
- DO NOT TOUCH the housing bare-hand during its operation. Turn OFF the power and allow approximately 15 minutes for the fixture to cool down before replacing or serving.



FIXTURE OVERVIEW



- 1. powerCON IN
- 2. Fuse
- 3. powerCON OUT
- 4. 3pin & 5pin DMX OUT
- 5. RJ45 NET OUT
- 6. MODE, UP, DOWN, ENTER Buttons
- 7. Mounting Bracket / Yoke
- 8. RJ45 NET IN
- 9. 3pin & 5pin DMX IN
- 10. LCD MENU Control Display



FIXTURE INSTALLATION



FLAMMABLE MATERIAL WARNING

Keep fixture at least 5.0 ft. (1.5m) away from any flammable materials, decorations, pyrotechnics, etc.



ELECTRICAL CONNECTIONS

A qualified electrician should be used for all electrical connections and/or installations.

ISP CAUTIONS

- For added protection, mount the fixture in areas outside walking paths, seating areas, or in areas were unauthorized personnel might reach the fixture.
- Ambient operating temperature range for this fixture is 5°F to 113°F (-15°C to 45°C).
 Do not use the fixture under or above this temperature.
- Before mounting the fixture to any surface, make sure the installation area can hold a minimum point load of 10 times the weight of the fixture.
- Fixture installation must always be secured with a secondary safety attachment, such as an appropriate safety cable.
- Never stand directly below the device when mounting, removing or servicing.

POWER LINKING

Max number of units that can be power linked is 4 units @110V and 9 units @240V.


CLAMP MOUNTING

The fixture provides an integrated yoke/rigging bracket. When mounting this fixture to truss be sure to secure an appropriately rated clamps to the yoke/rigging bracket using a M10 screw fitted through the center hole.



MOUNTING POINTS

- Overhead mounting requires extensive experience, including amongst others
 calculating working load limits, installation material being used, and periodic
 safety inspection of all installation material and the device. If you lack these
 qualifications, do not attempt the installation yourself. Improper installation can
 result in bodily injury.
- Fixture is fully operational in the specific mounting positions as illustrated below.



SAFETY CABLE

Always use a Safety Cable whenever installing this fixture in a suspended environment to ensure the fixture will not drop if the clamp fails.



FIXTURE MENU

ON-BOARD SYSTEM MENU


The fixture comes with an easy to navigate system menu. The next section will detail the functions of each command in the system menu.

LCD MENU CONTROL PANEL

The control panel (see image below) located on the top of the fixture allows you to access the main menu and make all necessary adjustments to the fixture. During normal operation, pressing **MODE** button once will access the fixture's main menu. Once in the main menu you can navigate through the different functions and access the sub-menus with the UP, and DOWN buttons. Once you reach a field that requires adjusting, press the ENTER button to activate that field and use the UP and **DOWN** buttons to adjust the field. Pressing the **ENTER** button once more will confirm your setting. You may exit the main menu at any time without making any adjustments by pressing the **MODE** button.



NOTE: the LCD Menu Control Display will shut OFF and lockout after 30 seconds of no use. Press and hold the **MODE** button for 10 seconds to unlock the LCD display.



INFORMATION DISPLAYED DURING INITIAL POWER ON

When the fixture is initially powered ON, the display shows the following information:

Software Update ELATION ACL CURTAIN V1.12 Please Wait... Fixture Software Version (Greater than or equal to)




		ELATION© ACL	CURTAIN™				
		SYSTEM	M E N U				
		ect to change without o	any prior written notice. Defaults In Bold.				
MENU	OPTIONS / VALUES		DESCRIPTION				
DMX MODE ADDR:001 CH:xx	ADDR: 001 - 512 1CH:04, 2CH:04 , CI CH:12, CH:28, CH:3		DMX Address Setting DMX Channel Mode				
SLAVE M O D E			Set Fixture To Slave Mode				
AUTO RUN FQN:xx	FQN:01-99		Set Number Of Times Each INTERNAL PROGRAM MACRO Repeats Before Moving To Next Macro.				
01.STATIC -	01.STATIC CL:RGB FADE00		Select INTERNAL PROGRAM MACRO.				
15.FLOW 10		' Arabita atural					
Dim Curve	Standard , Stage, TV Theatre	, AICHIIECIUIAI,	Set Desired Dimming Curve				
Pixel Flip	OFF, ON		Set Starting Pixel LED. See Pixel Flip Setting Section.				
NO DMX MOD	Hold, Blackout, Prog	ıram	Define How Fixture Reacts When NO DMX Signal Present.				
Manual	R000-255 G000-2 W000-255 Strobe		Set RGBW + Strobe values manually for ALL 7 LEDs.				
Macros	00- 64		Set Color Macro.				
Fan Set	Fan Speed Auto , High, Low		Set Fan Speed				
	Blacklight 02S-60S [C	058]	LCD Display Shutoff Time.				
LCD Set	Key Lock [OFF]		Set Control Display Key Lock Feature.				
	DispFlash [ON]		LCD Display flashes when NO Signal is detected.				
Temp	F ° , C°		Set temperature to F° / C°				
DFSE	OFF, ON		Restore Factory Settings.				
Info	Time.Info	Current: 0000H Total Time: 0000H Last Clear: 0000H Timer PIN: XXX Clear Last [OFF , ON]	Displays Internal Timers. Enter PIN= 066 To Access Clear Last Function.				
	Temp. Info	XXX F°	Displays Current Fixture Temperature.				
	Model. Info	ACL Curtain	Displays Model Name.				
	Software	1U:01 ≥V1.12 2U:01 ≥V1.09	Displays Software Versions. (Greater Than or Equal To)				
	Fixture ID Service PIN: XXX		Enter PIN= 050 to access Network Menus.				
Ethernet Set	Fixture ID Device IP Addr	000.000.000.000	Set Fixture IP Address. (Need to enter Service PIN to access this menu)				
	Universe	000 -255	Set DMX Universe number. (Need to enter Service PIN to access this menu)				
	Protocol Set	ArtNet, Kling-Net	Set Protocol.				
	Network Switch	ON, OFF	Set Ethernet switch.				



DIMMING CURVES

The **DimCurve** menu allows you to select one of the following preset dimming curves: **Standard, Stage, TV, Architectural, Theatre,** or **Default**.


(See diagram below for more details)



Ramp Effect	02	55 OS (Fade Time)	0 1S (Fade Time)		
namp Enect	Trise (ms)	Tdown (ms)	Trise (ms)	Tdown (ms)	
Standard	0	0	0	0	
Stage	780	1100	1540	1660	
TV	1180	1520	1860	1940	
Architectural	1380	1730	2040	2120	
Theatre	1580	1940	2230	2280	

PIXEL FLIP

Select the desired starting LED pixel and chase direction from one of the following modes below by pressing the **UP/DOWN** buttons and then pressing **ENTER** to confirm.





Flip = OFF

Flip = ON



DMX CHANNEL FUNCTIONS AND VALUES

ELATION© ACL CURTAIN™

DMX Channel Values / Functions Version 1 (63 DMX Channels)

Specifications are subject to change without any prior written notice.

*Control of LFDs depends on the Pixel Flin setting

	*Control of LEDs depends on the Pixel Flip setting.											
				DMX CF	IANNEL MO	ODE	1		1		VALUE	FUNCTION
1CH:04	2CH:04	6CH	1CH:08	2CH:08	10CH	12CH	56CH	58CH	60CH	63CH		16 BIT CHANNELS
	1	1	1	1	1	1					0.055	RED LED - All LEDS [1-14]
											0-255	Red (0-Black - 255-100%)
				2							0-255	RED LED FINE - All LEDS [1-14]
											0-255	Red (0-Black - 255-100%) GREEN LED - All LEDs [1-14]
	2	2	2	3	2	2					0-255	Green (0-Black - 255-100%)
											0 200	GREEN LED FINE - All LEDs [1-14]
				4							0-255	Green (0-Black - 255-100%)
				_		_						BLUE LED - All LEDs [1-14]
	3	3	3	5	3	3					0-255	Blue (0-Black - 255-100%)
				4								BLUE LED FINE - All LEDs [1-14]
				6							0-255	Blue (0-Black - 255-100%)
	4	4	4	7	4	4						WHITE LED - All LEDs [1-14]
	,	·	•	,							0-255	White (0-Black - 255-100%)
				8								WHITE LED FINE - All LEDs [1-14]
											0-255	White (0-Black - 255-100%)
							1	1	1	1		RED LED - LED [1]
											0-255	Red (0-Black - 255-100%)
							2	2	2	2		GREEN LED - LED [1]
											0-255	Green (0-Black - 255-100%)
							3	3	3	3		BLUE LED - LED [1]
							_	_	_	_	0-255	Blue (0-Black - 255-100%)
							4	4	4	4		WHITE LED - LED [1]
											0-255	White (0-Black - 255-100%)
							5	5	5	5		RED LED - LED [2]
							_	_	_		0-255	Red (0-Black - 255-100%)
							6	6	6	6		GREEN LED - LED [2]
											0-255	Green (0-Black - 255-100%)
							7	7	7	7		BLUE LED - LED [2]
							,	,	ŕ	,	0-255	Blue (0-Black - 255-100%)
							8	8	8	8		WHITE LED - LED [2]
							_	_	_	_	0-255	White (0-Black - 255-100%)
							9	9	9	9		RED LED - LED [3]
							,	,	,	,	0-255	Red (0-Black - 255-100%)
							10	10	10	10		GREEN LED - LED [3]
											0-255	Green (0-Black - 255-100%)
							11	11	11	11		BLUE LED - LED [3]
							' '	' '	1.1	' '	0-255	Blue (0-Black - 255-100%)
							12	12	12	12		WHITE LED - LED [3]
							12	12	12	12	0-255	White (0-Black - 255-100%)



DMX Channel Values / Functions Version 1 (63 DMX Channels)

Specifications are subject to change without any prior written notice.

*Control of LEDs depends on the Pixel Flip setting.

					IANNEL MO		penas on	IIIe rixei	LIID 961111	19.	VALUE	FUNCTION
1CH:04	2CH:04	6СН	1CH:08	2CH:08	10CH	12CH	56CH	58CH	60CH	63CH		16 BIT CHANNELS
							1.0	10	1.0	3.0		RED LED - LED [4]
							13	13	13	13	0-255	Red (0-Black - 255-100%)
							1.4	1.4	1.4	1.4		GREEN LED - LED [4]
							14	14	14	14	0-255	Green (0-Black - 255-100%)
							15	15	15	15		BLUE LED - LED [4]
							15	15	10	15	0-255	Blue (0-Black - 255-100%)
							16	16	16	16		WHITE LED - LED [4]
							10	10	10	10	0-255	White (0-Black - 255-100%)
							17	17	17	17		RED LED - LED [5]
							17	17	17	17	0-255	Red (0-Black - 255-100%)
							18	18	18	18		GREEN LED - LED [5]
							10	10	10	10	0-255	Green (0-Black - 255-100%)
							19	19	19	19		BLUE LED - LED [5]
							17	1,7	17	' '	0-255	Blue (0-Black - 255-100%)
							20	20	20	20		WHITE LED - LED [5]
											0-255	White (0-Black - 255-100%)
							21	21	21	21		RED LED - LED [6]
											0-255	Red (0-Black - 255-100%)
							22	22	22	22		GREEN LED - LED [6]
											0-255	Green (0-Black - 255-100%)
							23	23	23	23		BLUE LED - LED [6]
											0-255	Blue (0-Black - 255-100%)
							24	24	24	24		WHITE LED - LED [6]
											0-255	White (0-Black - 255-100%)
							25	25	25	25		RED LED - LED [7]
											0-255	Red (0-Black - 255-100%)
							26	26	26	26		GREEN LED - LED [7]
											0-255	Green (0-Black - 255-100%)
							27	27	27	27		BLUE LED - LED [7]
											0-255	,
							28	28	28	28	0.055	WHITE LED - LED [7]
											0-255	White (0-Black - 255-100%)
							29	29	29	29	0.055	RED LED - LED [8]
											0-255	Red (0-Black - 255-100%)
							30	30	30	30	0.055	GREEN LED - LED [8]
											0-255	Green (0-Black - 255-100%)
							31	31	31	31 31	0.055	BLUE LED - LED [8]
											0-255	Blue (0-Black - 255-100%)
							32	32	32	32	0.055	WHITE LED - LED [8]
											0-255	White (0-Black - 255-100%)



DMX Channel Values / Functions Version 1 (63 DMX Channels)

Specifications are subject to change without any prior written notice.

*Control of LEDs depends on the Pixel Flip setting.

					IANNEL MO		penas on	IIIE FIXEI	riib seiiii	ıy.	VALUE	FUNCTION
1CH:04	2CH:04	6СН	1CH:08	2CH:08	10CH	12CH	56CH	58CH	60CH	63CH		16 BIT CHANNELS
												RED LED - LED [9]
							33	33	33	33	0-255	Red (0-Black - 255-100%)
							34	2.4	34	34		GREEN LED - LED [9]
							34	34	34	34	0-255	Green (0-Black - 255-100%)
							35	35	35	35		BLUE LED - LED [9]
							30	30	30	33	0-255	Blue (0-Black - 255-100%)
							36	36	36	36		WHITE LED - LED [9]
											0-255	White (0-Black - 255-100%)
							37	37	37	37		RED LED - LED [10]
											0-255	Red (0-Black - 255-100%)
							38	38	38	38 38		GREEN LED - LED [10]
											0-255	Green (0-Black - 255-100%)
							39	39	39	39	0.055	BLUE LED - LED [10]
											0-255	Blue (0-Black - 255-100%)
							40	40	40	40	0-255	WHITE LED - LED [10]
											0-255	White (0-Black - 255-100%) RED LED - LED [11]
							41	41	41	41	0-255	
											0-200	Red (0-Black - 255-100%) GREEN LED - LED [11]
							42	42	42	42	0-255	Green (0-Black - 255-100%)
											0 200	BLUE LED - LED [11]
							43	43	43	43	0-255	Blue (0-Black - 255-100%)
												WHITE LED - LED [11]
							44	44	44	44	0-255	White (0-Black - 255-100%)
							45	45	45	45		RED LED - LED [12]
							45	45	45	45	0-255	Red (0-Black - 255-100%)
							46	46	46	46		GREEN LED - LED [12]
							40	40	40	40	0-255	Green (0-Black - 255-100%)
							47	47	47	47		BLUE LED - LED [12]
							47	47	47	47	0-255	Blue (0-Black - 255-100%)
							48	48	48	48		WHITE LED - LED [12]
											0-255	White (0-Black - 255-100%)
							49	49	49	49		RED LED - LED [13]
											0-255	Red (0-Black - 255-100%)
							50	50	50	50	0.5==	GREEN LED - LED [13]
											0-255	Green (0-Black - 255-100%)
							51	51	51	51	0.055	BLUE LED - LED [13]
	-										0-255	Blue (0-Black - 255-100%)
							52	52	52	52	0.055	WHITE LED - LED [13]
											0-255	White (0-Black - 255-100%)



DMX Channel Values / Functions Version 1 (63 DMX Channels)

Specifications are subject to change without any prior written notice.

	*Control of LEDs depends on the Pixel Flip setting. DMX CHANNEL MODE VALUE FUNCTION											
	1			DMX CH	IANNEL MO	ODE					VALUE	FUNCTION
1CH:04	2CH:04	6CH	1CH:08	2CH:08	10CH	12CH	56CH	58CH	60CH	63CH		16 BIT CHANNELS
							53	53	53	53		RED LED - LED [14]
							3	30	30	33	0-255	Red (0-Black - 255-100%)
							54	54	54	54		GREEN LED - LED [14]
							54	54	54	54	0-255	Green (0-Black - 255-100%)
							55	55	55	55		BLUE LED - LED [14]
							00	00	00	00	0-255	Blue (0-Black - 255-100%)
							56	56	56	56		WHITE LED - LED [14]
								00		00	0-255	White (0-Black - 255-100%)
												COLOR MACROS
											0	NO Function
											1-4	Color Macro 01
											5-8	Color Macro 02
											9-12	Color Macro 03
											13-16	Color Macro 04
											17-20	Color Macro 05
											21-24	Color Macro 06
											25-28	Color Macro 07
											29-32	Color Macro 08
											33-36	Color Macro 09
											37-40	Color Macro 10
											41-44	Color Macro 11
											45-48	Color Macro 12
											49-52	Color Macro 13
											53-56	Color Macro 14
1			5			5					57-60	Color Macro 15
'			Ŭ			Ü					61-64	Color Macro 16
											65-68	Color Macro 17
											69-72	Color Macro 18
											73-76	Color Macro 19
											77-80	Color Macro 20
											81-84	Color Macro 21
											85-88	Color Macro 22
											89-92	Color Macro 23
											93-96	Color Macro 24
											97-100	Color Macro 25
											101-104	Color Macro 26
											105-108	Color Macro 27
											109-112	Color Macro 28
											113-116	Color Macro 29
											117-120	Color Macro 30
											121-124	Color Macro 31
											125-128	Color Macro 32



DMX Channel Values / Functions Version 1 (63 DMX Channels)

Specifications are subject to change without any prior written notice.

*Control of LEDs depends on the Pixel Flip setting.

	UNCTION IT CHANNELS [continued]
COLOR MACROS 129-132 Color Macro 33	
129-132 Color Macro 33	[continued]
133-136 Color Macro 34	
100 100 Color Macio 04	
137-140 Color Macro 35	
141-144 Color Macro 36	
145-148 Color Macro 37	
149-152 Color Macro 38	
153-156 Color Macro 39	
157-160 Color Macro 40	
161-164 Color Macro 41	
165-168 Color Macro 42	
169-172 Color Macro 43	
173-176 Color Macro 44	
177-180 Color Macro 45	
181-184 Color Macro 46	
185-188 Color Macro 47	
1 5 5 189-192 Color Macro 48	
193-196 Color Macro 49	
197-200 Color Macro 50	
201-204 Color Macro 51	
205-208 Color Macro 52	
209-212 Color Macro 53	
213-216 Color Macro 54	
217-220 Color Macro 55	
221-224 Color Macro 56	
225-228 Color Macro 57	
229-232 Color Macro 58	
233-236 Color Macro 59	
237-240 Color Macro 60	
241-244 Color Macro 61	
245-248 Color Macro 62	
249-252 Color Macro 63	
253-255 Color Macro 64	
SHUTTER / STROBE	
0-31 NO Function	
32-63 LEDs ON	
64-95 Strobe Effect SLOV	W to FAST
2 6 5 6 57 57 96-127 LEDs ON	
128-159 Pulse Effect In Sec	quence SLOW to FAST
160-191 LEDs ON	
192-223 Random Strobe El	ffect SLOW to FAST
224-255 LEDs ON	



DMX Channel Values / Functions Version 1 (63 DMX Channels)

Specifications are subject to change without any prior written notice.

*Control of LEDs depends on the Pixel Flip setting.

				DMX CH				erias orri		'	VALUE	FUNCTION
1CH:04	2CH:04	6СН	1CH:08	2CH:08	10CH	12CH	56CH	58CH	60CH	63CH		16 BIT CHANNELS
3		5	7		6	7		57	58	58		MASTER DIMMER
3		3	/		0	/		37	36	36	0-255	0 to 100%
4		6	8		7	8		58	59	59		DIMMER FINE [16BIT]
4		O	O		,	0		30	07	07	0-256	1 to 100%
												AUTO PROGRAMS
											0	NO FUNCTION
											1-20	PROGRAM MACRO 01
											21-40	PROGRAM MACRO 02
											41-60	PROGRAM MACRO 03
											61-80	PROGRAM MACRO 04
											81-100	PROGRAM MACRO 05
					8	9				60	101-120	PROGRAM MACRO 06
					0	7				00	121-140	PROGRAM MACRO 07
											141-160	PROGRAM MACRO 08
											161-180	PROGRAM MACRO 09
											181-200	PROGRAM MACRO 10
											201-220	PROGRAM MACRO 11
											221-240	PROGRAM MACRO 12
											241-250	PROGRAM MACRO 13
											251-255	PROGRAM MACRO 14
					9	10				61		AUTO PROGRAM SPEED
					7	10				01	0-255	Program Speed SLOW to FAST
					10	11				62		AUTIO PROGRAM FADE
					10	- 11				02	0-255	Program Fade SLOW to FAST
												DIMMING CURVE MODES
											0-20	STANDARD
											21-40	STAGE
						12			60	63	41-60	TV
											61-80	ARCHITECTURAL
											81-100	THEATRE
											101-255	Default to Unit Setting



CLEANING AND MAINTENANCE



CAUTION

Disconnect power before cleaning or maintenance.

CLEANING

Frequent cleaning is recommended to insure proper function, optimized light output, and an extended life. The frequency of cleaning depends on the environment in which the fixture operates: damp, smoky or particularly dirty environments can cause greater accumulation of dirt on the fixture's optics.

- Clean the external lens surface at least every 20 days with a soft cloth to avoid dirt/debris accumulation.
- Never use alcohol, solvents, or ammonia based cleaners.

MAINTENANCE

Regular inspections are recommended to insure proper function and extended life. There are no user serviceable parts inside this fixture, please refer all other service issues to an authorized Elation service technician. Should you need any spare parts, please order genuine parts from your local Elation dealer.

Please refer to the following points during routine inspections:

- A detailed electric check by an approved electrical engineer every three months, to make sure the circuit contacts are in good condition and prevent overheating.
- Be sure all screws and fasteners are securely tightened at all times. Lose screws
 may fall out during normal operation resulting in damage or injury as larger parts
 could fall.
- Check for any deformations on the housing, color lenses, rigging hardware and
 rigging points (ceiling, suspension, trussing). Deformations in the housing could
 allow for dust to enter into the fixture. Damaged rigging points or unsecured
 rigging could cause the fixture to fall and seriously injure a person(s).
- Electric power supply cables must not show any damage, material fatigue or sediments. Never remove the ground prong from the power cable.



TECHNICAL SPECIFICATIONS

SOURCE

(14) 15W RGBW 4-in-1 LEDs

100,000 Hour Average Lamp Life*

*May vary depending on several factors including but not limited to: Environmental Conditions, Power/Voltage, Usage Patterns (On-Off Cycling), Control, and Dimming.

EFFECTS

Individual Pixel Control
Strobe and Selectable Dimming Curves

COLOR

RGBW

CONTROL / CONNECTIONS

(11) DMX Channel Modes (1CH:04 / 2CH:04 / 6 / 1CH:08 / 2CH:08 / 10 / 12 / 56 / 58 / 60 / 63)

RDM (Remote Device Management)

4 Button Touch Control Panel

Full Color 180° Reversible LCD Menu Display

3pin/5pin DMX In/Out

RJ45 Ethernet In/Out (Art-NET)

powerCON Power In/Out

SIZE / WEIGHT

Length: 43.3" (1100mm)

Width: 9.5" (241.2mm) (Glare Shield Installed)

Vertical Height: 6.8" (172.5mm) Weight: 24.0 lbs. (10.9 kg)

ELECTRICAL / THERMAL

AC 100-240V - 50/60Hz 240W Max Power Consumption 5F to 113°F (-15°C to 45°C)

APPROVALS / RATINGS


CE | IP30



Please Note: Specifications and improvements in the design of this unit and this manual are subject to change without any prior written notice.



PHOTOMETRIC DATA



	1 m	3.3 ft
53° Beam Diameter	0.98	3.2
62° Field Diameter	1.17	3.8
	lux	fc
RED LEDs	7,902	734
GREEN LEDs	18,770	1,744
BLUE LEDs	4,537	421
WHITE LEDs	19,590	1,820
FIIII ON	46,740	4,342

2 m	6.6 ft
1.94	6.4
2.39	7.8
lux	fc
3,652	339
9,134	849
1,924	179
11,330	1,053
20,890	1,941

3 m	9.8 ft	
2.95	9.7	
3.58	11.7	
lux	fc	
2,440	227	
5,740	533	
1,337	124	
6,714	624	
13,520	1,256	


4 m	13.1 ft	
3.95	13.0	
4.7	15.4	
lux	fc	
1,757	163	
4,040	375	
951	88	
5,064	470	
9,717	903	

5 m	16.4 ft		
4.91	16.1		
5.85	19.2		
lux	fc		
1,313	122		
2,971	276		
761	71		
3,855	358		
7,664	712		

Please Note: Specifications and improvements in the design of this unit and this manual are subject to change without any prior written notice.



DIMENSIONAL DRAWINGS



Please Note: Specifications and improvements in the design of this unit and this manual are subject to change without any prior written notice.



OPTIONAL ACCESSORIES

ORDER CODE	ITEM		
TRIGGER CLAMP	Heavy Duty Wrap Around Hook Style Clamp		
EWDMXSYSTEM	Wireless DMX System (1 Transmitter, 1 Receiver)		
PLC3	3' (1m) powerCON PRO Link Cable		
AC3PDMX5PRO	5 ft. (1.5m) 3pin PRO DMX Cable		
AC5PDMX5PRO	5 ft. (1.5m) 5pin PRO DMX Cable		
CAT005	5' (1.5m) CAT6 EtherCON Cable		
	Additional Cable Lengths Available		